


4-30-1412 - Digital Signetic parts list



1)	PCB HI END	4-10-1501A	10)	"D" RING/GASKET	4-60-1402	18)	PRESSURE SWITCH	4-10-1812
1A)	PCB LOW END	4-10-1504A	11)	TAIL PIEACE 2"	4-60-1902	19)	3x6 RECTANGLE GASKET	4-60-0604
2)	TRANSFORMER	4-10-1931		TAIL PIEACE IF 1"	4-60-1904B	20)	3x6 RECTANGLE CONTROL	1-629L
3)	TEMPERATURE SENSOR	4-10-1919A	12)	BUSS BAR	4-10-0102A	21)	BLOWER REC. 120V	4-10-1701
5)	CAPILLARY COVER	4-40-0201	13)	MAIN POWER TERMINAL	4-10-1912		IF 240V	4-10-1707
6)	4 KW ELEMENT	4-10-0707A	14)	AUXILIARY REC.	4-10-1701	22)	PUMP1 REC.	4-40-1704
	IF 5.5 KW	4-10-0710		IF CIRC PUMP REC	4-10-1703	23)	PILOT LIGHT	4-10-1511
7)	RELAY	4-10-1727	15)	PUMP 2 REC.	4-10-1705	24)	MANUAL	4-30-0202A
8)	HEATER BODY	4-40-0102	16)	OZONE REC.	4-10-1702			
9)	HEATER NUT	4-60-1302	17)	LIGHT CORD	4-10-0208			